

Mason Jar Bathroom Organizer



Additional Tools Required:

- Flat head screwdriver or drill
- Drill or drill press
- Hammer
- Measuring tape or ruler

Project Instructions:

1. Choose your piece of wood. Finish it with stain, paint or leave natural for a reclaimed look.

(Example uses 1" x 8" x 24" piece of wood with Minwax White Wash Pickling Stain, Rust-Oleum Aged Gray Chalked Paint and Rust-Oleum Charcoal Chalked Paint.)

Estimated Project Time:

1 hour

(Additional time depending on wood finish)

SKU	Supplies
630464	(3) Pint regular mouth mason jars
428068	(3) 1 ¼" – 2 ¾" steel pipe clamps
484660	(2) ½" black pipe flange
419982	(2) 90° ½" black pipe elbows
422444	(2) ½" black pipe caps
476390	(4) ½" black pipe closes
702536	(11) #10 ¾" wood screws
203167	(1) Large D-ring hooks

Optional Items:

SKU	Supplies
784917	Minwax white wash pickling stain
771256	Rust-Oleum aged gray
771291	Charcoal chalked paint
602461	Transform mason pump insert kit
602465	Transform mason frog jar lid insert
N/A	Back mount material



Figure 1

2. Measure and mark where the mason jars will be mounted. Measurements may vary depending on the size of wood.

(In our example, screw holes for mason jars were marked 6" apart and 2 ½" from top of board.)

3. Pre-drill the wood on the marks to make attaching clamps to wood easier.
4. Here's the tricky part: count 22-24 "slots" in from the end of the steel clamp. This will position the joint to the side, but give you enough room to tighten as needed. Then drill a hole in this slot large enough for the screw to fit through, but small enough for the head of the screw to hold securely. The drill bit will want to slip off of the steel so you will need to put some "elbow grease" into it or use a drill press if you have one.
5. Screw the open clamp to the board putting screw through hole and lining up with pre-drilled hole in wood. You should be able to tighten by hand with a screwdriver.



Figure 2

6. Put the mason jars in clamps, with the clamp around the narrowest part of the neck and tighten until secure.
7. Next assemble the towel hooks by connecting the black pipe end cap to a 1/2" threaded pipe close, and a 1/2" threaded pipe close to each end of the 90° 1/2" pipe elbow. Wait to attach to the 1/2" black pipe flange.

8. Place the flange at desired location on the board and mark the holes for each screw and remove flange. Pre-drill the holes before placing the flange back in place. Screw the flange in place using screwdriver or drill. Next, twist the pipe "hook" (made in step 7) into each flange to create towel hooks.



Figure 3

9. Add additional items such as Transform Mason pump insert kits for soaps and lotions or Transform Mason frog jar lid insert to keep toothbrushes clean and organized. Use the remaining mason jars to store toothpaste, q-tips, cotton balls, or turn it into a night light. The possibilities are endless!



Figure 4